PRODUCT SAFETY SHEET

Read this BEFORE you use the equipment Please ensure:

- The operator has read and understood the operating manual.
- If the equipment is connected to a mains power supply, ensure that the equipment is properly earthed and the correct supply voltage used.
- The working area is well ventilated and illuminated.
- The equipment is not subjected to damp or liquid spray.
- The equipment is never used in a hazardous environment.
- The operator has read and understood all Materials Safety Data Sheets before use, and is fully familiar with any hazards and necessary precautions.
- All reagents are sealed tightly after use and cannot leak.
- All equipment is emptied of reagents and oil after use and thoroughly cleaned.
- Equipment is only used for its intended use; using it any other way may impair any safety protection.
- No smoking during use of the equipment or when handling any of the reagents.
- Use protective goggles and gloves.

Use of pressure cells

Some tests require the use of pressure cells. They are safety tested at pressures 10 times normal use.

- Do not exceed the recommended volumes of reagents or test oils in the cell.
- The cell is designed to gently vent excess pressure when opened. Hold the cell upright, away from the body and slacken the cap slowly to release the pressure and prevent any liquid being sprayed out.